



AxesPOS NET

CONFIGURATION MANUAL



V3.3 rev.1

April 4th, 2008

Table of Contents

1.	Admin Functions.....	3
1.1	Card Info	4
1.2	Queries	4
1.3	Reports	4
1.4	SAM Info	4
1.5	Set Date/Time	4
1.6	Add User	4
1.7	Remove User.....	4
1.8	Edit User	4
1.9	Edit IP Configuration	4
1.10	IP Status	4
1.11	Ask Files	4
1.12	Edit Configuration	5
1.12.1	Company Name	5
1.12.2	Print Enable.....	5
1.12.3	Reprint Enable	5
1.12.4	Double Receipt.....	6
1.12.5	Low SAM Balance Warning.....	6
1.12.6	Maximum SAM Balance	6
1.12.7	Maximum User Balance	6
1.12.8	Enable	6
1.12.9	Communication Type.....	6
1.12.10	Debug Beep Level.....	6
1.12.11	Debug Msg Level.....	6
1.12.12	Limit Promotion – One per Day	6
1.13	Reset Term	7
1.14	Chg Admin PWD.....	7
2.	User and Secret Code.....	8

1. Admin Functions

To access Admin Menu, you should enter your ADMIN PWD at the login screen (accessed by pressing the FUNC key). If you lose your ADMIN Secret Code, you should contact AxesNetwork Solution with the number at the bottom of the screen. AxesNetwork will be able to give you a new Secret Code to Unlock your reader.

LOGIN
Enter SecretCode

1234ABCD

This is the ADMIN MENU

FUNCTIONS
01.CARD INFO
02.QUERIES
03.REPORTS
04.SAM INFO
05.SET DATE/TIME
06.ADD USER
<Enter>: Next Page

FUNCTIONS
07.REMOVE USER
08.EDIT USER
09.EDIT IP CFG
10.IP STATUS
11.ASK FILE
12.EDIT CONFIG
<Enter>: Next Page

FUNCTIONS
13.RESET PWD
14.RESET TERM
15.CHG ADMIN PWD

1.1 Card Info

See Functions Screen Section of the User's Manual.

1.2 Queries

See Functions Screen Section of the User's Manual.

1.3 Reports

See Functions Screen Section of the User's Manual.

1.4 SAM Info

See Functions Screen Section of the User's Manual.

1.5 Set Date/Time

See Functions Screen Section of the User's Manual.

1.6 Add User

See Functions Screen Section of the User's Manual.

This option should not be used in online mode. Any changes made locally will not be reflected on the web interface and will therefore be cancelled at the next synchronization.

1.7 Remove User

See Functions Screen Section of the User's Manual.

This option should not be used in online mode. Any changes made locally will not be reflected on the web interface and will therefore be cancelled at the next synchronization.

1.8 Edit User

See Functions Screen Section of the User's Manual.

This option should not be used in online mode. Any changes made locally will not be reflected on the web interface and will therefore be cancelled at the next synchronization.

1.9 Edit IP Configuration

See Functions Screen Section of the User's Manual.

1.10 IP Status

See Functions Screen Section of the User's Manual.

1.11 Ask Files

See Functions Screen Section of the User's Manual.

1.12 Edit Configuration

This menu allows you to change the main parameters of the reader.

EDIT CONFIG
01. AxesNetwork
02.PRINT ENABLE
03.REPRINT ENABL
04.DOUBLE TICKET
05.LOW SAM WARN
06.MAX SAM BAL
<Enter>: Next Page

EDIT CONFIG
07.MAX USER BAL
08.ENABLE POS
09.COMM TYPE
10.DEBUG BEEP
11.DEBUG MSG
12.LIMIT PROMO

This is a typical parameter screen.

PARAMETER
MAX USER BAL - 0.01\$
Min: 00000000
Max: 00032735
ACTUAL VALUE:
00075
NEW VALUE:
00075

1.12.1 Company Name

Company Name that will be printed on receipt.

DEFAULT VALUE: AxesNetwork

1.12.2 Print Enable

0: No Receipt Printing

1: Receipt Printing (DEFAULT VALUE)

1.12.3 Reprint Enable

0: No Last Receipt Re-Printing

1: Last Receipt Re-Printing using the <REPRINT> key (DEFAULT VALUE)

1.12.4 Double Receipt

0: No double Receipt (DEFAULT VALUE)

1: Double Receipt Enable.

The first copy will be marked be “Costumer’s Copy” and the second by “Merchant’s Copy”.

1.12.5 Low SAM Balance Warning

Level of the warning threshold for the SAM Balance. Indicate to the Manage to reload the reader with the BANK CARD.

DEFAULT VALUE : 1000.00\$ or 100 000 units

1.12.6 Maximum SAM Balance

Maximum SAM Balance Value.

DEFAULT VALUE : 1 000 000.00\$ or 100 000 000 units

1.12.7 Maximum User Balance

Maximum USER Purse Balance Value.

DEFAULT VALUE : 5 000.00\$ or 500 000 units

Note: This value should be the same as the Maximum User Balance configured in the AXESCOIN reader.

1.12.8 Enable

0: Enable (DEFAULT VALUE)

1: Disable

1.12.9 Communication Type

0: OFFLINE, NO LOG

1: ONLINE WITH LOG (DEFAULT VALUE)

2: OFFLINE WITH LOG

Changing this option to any value different than 1 will reset the users on this terminal to their default values, any counters, secret codes and description will be lost. Changing this value from 0 or 2 to 1 will not delete any existing users until the next synchronization at which point, the online users will replace the local users.

1.12.10 Debug Beep Level

1: Don’t touch this. The POS could stop working properly.

1.12.11 Debug Msg Level

0: Don’t touch this. The POS could stop working properly.

1.12.12 Limit Promotion – One per Day

0: Don’t limit promotion

1: Limit promotion to one per day.

1.13 *Reset Term*

This function reset the entire Reader Parameters to their virgin value. You should use to reset the reader before sending it to a different customer or after testing it in a production phase.

1.14 *Chg Admin PWD*

This function allows you to change the actual Admin Password.

2. User and Secret Code

DEFAULT VALUE

CASHIER

Description: CAS0001

PWD: 1111

SUPERVISOR

Description: SUP0002

PWD: 222222

MANAGER

Description: MAN0003

PWD: 333333