



AxesNet

INSTALLATION MANUAL



V1.00 rev1

October 31th, 2007

1. SAM Usage

Before delivering any machine, you should insert its valid SAM in the SAM connector of the AxesCOIN.

2. Connector Pinout (Machine Side)

ORANGE: 12V

BLACK: Ground

RED: 5V

GREEN: KEY OUT COUNTER (Machine's view)

BLUE: Enable (Machine's view) (Not used)

GREY: COIN IN (Machine's view)

YELLOW: CASH COUNT

BROWN: OTHER COUNT

Note: The reader needs both 5V and 12V.

3. Ground Reference

IMPORTANT:

To avoid any Electromagnetic Static Discharge (ESD) problem, you should connect the green wire included between one of the 4 bolts holding the reader in place into the machine and a good ground reference. The nut will keep in place the Ring Terminal and will do a good electrical contact.

The other end of this cable should go through a good ground reference and a large metal frame. We suggest using a screw on the power supply. You should use a #18AWG wire or bigger.

4. Electrical Safety

This product has not been evaluated for connection to a Class I power system (AC distribution system having a direct connection to earth according to IEC 60950).

You should use a Power Supply Class II. This product is designed to be used in a dry environment.