Poker Master

Dip Switch No. 1		1	2	4	3	5	6	7	8
Freeze Pair on (CM)	Not Active	OFF							
	Active	ON							
Hopper Out Switch	Active High		OFF						
	Active Low		ON						
Type of Payout	Pay Out Switch			OFF					
	Automatic			ON					
7 Card In W-Up	Lose				OFF				
	Even				ON				
W-Up Game Payout Rate	70%					OFF			
	80%					ON			
W-Up Game	OFF						OFF		
	ON						ON		
Bet Max.	16 Bet							OFF	OFF
	32 Bet							ON	OFF
	64 Bet							OFF	ON
	96 Bet							ON	ON

Dip Switch No. 2	PCH	PCH	PCH	PCH	1	2	3	4	5	6	7	8
Pay Out Rate	3-80	3-30	3-20	3-15								
	90%	70%	70%	85%	OFF	OFF	OFF					
	85%	65%	65%	80%	ON	OFF	OFF					
	80%	60%	60%	75%	OFF	ON	OFF					
	75%	55%	55%	70%	ON	ON	OFF					
	70%	50%	50%	65%	OFF	OFF	ON					
	65%	45%	30%	63%	ON	OFF	ON					
	60%	40%	25%	60%	OFF	ON	ON					
	55%	30%	20%	15%	ON	ON	ON					
Hopper Limit	300							OFF	OFF			
	500							ON	OFF			
	1000							OFF	ON			
	Unlimited							ON				
Sounds 100 Odds	Off									OFF		
	ON									ON		
Key In Type	B type										OFF	
	A type										ON	
Type of Coin D	D type											OFF
	C type											ON

Dip Switch No. 3		1	2	3	4	5	6	7	8
Key In Rate	A Type			B Type					
	1 Coin 50 Credits	ON	ON	1 Coin 50 Credits					
	1 Coin 25 Credits	OFF	ON	1 Coin 25 Credits					
	1 Coin 10 Credits	ON	OFF	1 Coin 10 Credits					
	1 Coin 5 Credits	OFF	OFF	1 Coin 5 Credits					
Coin A Rate	1 Coin 10 Credits			ON	ON				
	1 Coin 5 Credits			OFF	ON				
	1 Coin 2 Credits			ON	OFF				
	1 Coin 1 Credit			OFF	OFF				
Coin D Rate	C Type	D Type							
	1 Coin 5 Credits	1 Coin 2 Credits				OFF	OFF		
	1 Coin 10 Credits	1 Coin 1 Credit				ON	OFF		
	1 Coin 25 Credits	2 Coins 1 Credit				OFF	ON		
	1 Coin 50 Credits	5 Coins 1 Credit				ON	ON		
Coin C Rate	1 Coin 1 Credit							OFF	OFF
	1 Coin 2 Credits							ON	OFF
	1 Coin 5 Credits							OFF	ON
	1 Coin 10 Credits							ON	ON

Dip Switch No. 4		1	2	3	4	5	6	7	8
Credit Limit	Unlimited	ON	ON	ON					
	100,000	OFF	ON	ON					
	50,000	ON	OFF	ON					
	40,000	OFF	OFF	ON					
	30,000	ON	ON	OFF					
	20,000	OFF	ON	OFF					
	10,000	ON	OFF	OFF					
	5,000	OFF	OFF	OFF					
Display of Credit Limit (CM Only)	ON				ON				
	OFF				OFF				
Bet Limit for Center Super 7	Limited					ON			
	Unlimited					OFF			
Minimum Bet for Bonus Play	8 Bet						ON		
	16 Bet						OFF		
Reel Speed (CM Only)	Fast							ON	
	Slow							OFF	
Hopper Out by Coin A	ON								ON
	OFF								OFF

Dip Switch No. 5		EZ Spin	1	2	3	4	5	6	7	8
Display of Doll on Demo	Displayed		ON							
	Not Displayed		OFF							
Coin In Limit (Check Credit Limit SW 4)	20,000			ON	ON					
	10,000			OFF	ON					
	5,000			ON	OFF					
	1,000			OFF	OFF					
Condition for 3 kind of bonus	3 - 2 - 1					ON	ON			
	6 - 3 - 1					OFF	ON			
	9 - 5 - 1					ON	OFF			
	12 - 7 - 1					OFF	OFF			
Display of Doll on Fr. & C. Bonus	Displayed							ON		
	Not Displayed							OFF		
Coin Out Rate	10	500							ON	
	1	100							OFF	
Run Cards in W - Up	ON									ON
	OFF									OFF

Dip Switch No. 6		1	2	3	4	5	6	7	8
Card Type	Cards	OFF							
	Missiles	ON							
Type Of W - Up Game	Big/Small		OFF						
	Red/Black		ON						
Hold after 1st Hold	Not Active			OFF					
	Active			ON					
Royal Win	Not Active				OFF				
	Active				ON				
Joker	Not Active					Off			
	Active					ON			
One Pair Win Type	No Win						OFF	OFF	OFF
	Any Pair						ON	OFF	OFF
	6 & Better						OFF	ON	OFF
	10 & Better						ON	ON	OFF
	J & Better						OFF	OFF	ON
	Q & Better						ON	OFF	ON
	K & Better						OFF	ON	ON
	Ace Pair						ON	ON	ON

Dip Switch No. 7			1	2	3	4	5	6	7	8
Minimum Bet to Play	1		OFF	OFF						
	5		ON	OFF						
	8		OFF	ON						
	10		ON	ON						
Keys Panel Type	A Type				OFF	OFF				
	B Type				ON	OFF				
	C Type				OFF	ON				
	D Type				ON	ON				
Chance Bonus	Not Active						OFF			
	Active						ON			
Sound at RUN and Open Cards	Not Active							OFF		
	Active							ON		
Main Game Type	CM Only	Full Demo of CM							OFF	OFF
	Poker Only	Full Demo of Poker							ON	OFF
	Both	Full Demo of Both Games							OFF	ON
	Both	Only Logo Demo of Both Games							ON	ON