

2-14-15, SETOGUCHI, HIRANO-KU, OSAKA 547, JAPAN TEL:+81-6-707-1181 FAX:+81-6-707-1919

Page 1/

《CHERRY MASTER'97》

DIP SW [No.1	1	1	2	3	4	5	6	7	8
Double Up Game	Used	ON							
On/Off	Not Used	OFF							
Double Up Game	5 Cards		ON						
Type	3 Cards		OFF						
Not Used				ON					
				OFF					
Not Used					ON				
					OFF				
Payout Type	Payout SW					ON			
	Automatic					OFF			
Spinning Speed	High		9				ON		
	Low	100	4				OFF		
Hopper Out	Active High							ON	
Micro Switch	Active Low	7 Sept. 1						OFF	
Odds Over 100	0 n								ON
Sound necessary	Off .								OFI

DIP SW [No. 2	2 .)		1	2	3	4	5	6	7	8
	55	%	ON	ON	ON				7. 1	
	60	%	OFF	ON	ON					
	65	%	ON	OFF	ON					
Payout Ratio	70	%	OFF	OFF	ON					
	75	%	ON	ON	OFF					
	80	%	OFF	ON	OFF					
	85	%	ON	OFF	OFF					
	90	%	OFF	OFF	OFF					
	8	Bet				ON	ON			
Bet Max.	16	Bet				OFF	ON			
	32	Bet				ON	OFF			
	64	Bet				OFF	OFF			
Bet Limit	8	Bet						ON		
For Any Bonus	16	Bet						0FF		
Type of Key In	KeyIn Type A			for						
	KeyIn	Type B	Dip No. 3-1, 2				-	OFF		
Type of Coin D	CoinD	Type A	A for							ON
	CoinD '	Type B	Dip No. 3-5, 6							OFF



2-14-15, SETOGUCHI, HIRANO-KU, OSAKA 547, JAPAN TEL:+81-6-707-1181 FAX:+81-6-707-1919

Page 2/

《CHERRY MASTER'97》

DIP	SW [No.3]	1	2	3	4	5	6	7	8	Note
	Type A	!			Typ	e B				
	1 coin 10 credit	ON	ON	lco	in	5 cr	edit			See
Key In	1 coin 20 credit	OFF	ON	lco	în 1	0 cr	edit			Dip No.2-7
Rate	1 coin 50 credit	ON	OFF	lco	in 2	25 credit				
	1 coin 100 credit	OFF	OFF	160	in 5	0 cr	edit			
	1 coin 1 credit			ON	ON					
Coin A	1 coin 2 credit			OFF	ON					
Rate	1 coin 5 credit			ON	OFF					
	1 coin 10 credit			OFF	OFF					
	Type A	Type B								
Coin D	1 coin 5 credit	1 c	oin	2 cr	edit	ON	ON			See
Rate	1 coin 10 credit	1 c	oin	1 cr	edit	OFF	ON			Dip No.2-8
(Token)	1 coin 25 credit	2 с	oin	l cr	edit	ON	OFF			
	1 coin 50 credit	5 с	oin	l cr	edit	OFF	OFF			
	1 coin 1 credit							ON	ON	
Coin C	1 coin 2 credit			-				0FF	ON	
Rate	1 coin 5 credit							ON	OFF	
	1 coin 10 credit							0FF	OFF	

DIPSW	[No. 4]	1	2	3	4	5	6	7	8	Note
	Unlimited	ON	ON	ON						
	100,000	OFF	ON	ON						
limit for	50.000	ON	OFF	ON						
Credit	40,000	OFF	OFF	ON						
	30,000	ON	ON	OFF						
	20,000	OFF	ON	OFF						
	10,000	ON	OFF	OFF						
	5,000	OFF	OFF	OFF						
	20,000				ON	ON				
Limit for	10,000				OFF	ON				
Coin In	5,000				ON	OFF				
	1,000				OFF	OFF				
	Unlimited						ON	ON		
Limit for	1,000						OFF	ON		
Hooper Payout	500						ON	0FF		
	300						OFF	OFF		
Coin A for	Exchange								ON	
Exchange	Not exchange						3		OFF	



2-14-15, SETOGUCHI, HIRANO-KU, OSAKA 547, JAPAN TEL:+81-6-707-1181 FAX:+81-6-707-1919

Page 3/

« CHERRY MASTER ' 97»

DIP SW [No.5]	1	2	3	4	5	6	7	8	
	Type A	ON	ON						
Pannel Type	Type B	OFF	ON						
•	Type C	ON	OFF						
	Type D	OFF	OFF						
Skill Stop	Used			ON					
0n/0ff	Not Used			OFF					
All Stop	Used				ON				
On/Off	Not Used				OFF				
Bonus Games	3 • 2 • 1					ON			
Entry Condition	6 • 3 • 1					OFF			
Not Used							ON		
							OFF		
Jackpot Initial	1000 / 2000							ON	
Base / Max.	1000 / 3000							OFF	
Joker Initial	500 / 2000								ON
Base / Max.	1000 / 2000								OFF