

MAGICAL ODDS

**Dip SW 2		1	2	3	4	5	6	7	8
PAY OUT {%	54%	on	on	on					
	58%	off	on	on					
	62%	on	off	on					
	66%	off	off	on					
	70%	on	on	off					
	74%	off	on	off					
	78%	on	off	off					
	82%	off	off	off					
*NUD LADY *in the screen and In w/up			yes no		on off				
ALWAYS						on	on		
ALWAYS								on	
ALWAYS									on

Dip SW 3

hopper limit		1	2	3	4	5	6	7	8
no limit		on	on						
1,000		off	on						
500		on	off						
300		off	off						
Maximum of bet	8			on	on				
	16			off	on				
	32			on	off				
	64			off	off				
Credit limit									
No limit						on	on	on	
90,000						off	on	on	
10,000						on	off	off	
40,000						off	off	on	
30,000						on	on	off	
50,000						on	off	on	
10,000						on	off	off	
5,000						off	off	off	

SW#8 SKILL STOP BY START (ON) OFF BY SMALL

MAGICAL ODDS

Dip SW#4

COIN IN LIMIT	1	2	3	4	5	6	7	8
IN NO LIMIT	off	off						
3,000	on	off						
2,000	off	on						
1,000	on	on						
HOPPER SWITCH								
N/C			on					
N/O			off					
always				on				
COIN D								
1coin 1credit					off	off	off	off
2credit					on	off	off	off
3credit					off	on	off	off
4credit					on	on	off	off
5credit					off	off	on	off
10credit					on	off	on	off
2 5credit					off	on	on	off
2 3credit					on	on	on	off
2 1credit					off	off	off	on
3 1credit					on	off	off	on
3 2credit					off	on	off	on
4 3credit					on	on	off	on
4 1credit					off	off	on	on
5 2credit					on	off	on	on
5 1credit					off	on	on	on
10 1credit					on	on	on	on

TO CLEAR MEMORY PUSH TEST/ Switch and put power on.
ON the screen this will be test MODE press BET then SMALL.
MEMORY CLEAR

MAGICAL ODDS**Other Features And Information****EDGE CONNECTOR LAYOUT**

PARTS	WIRE COLOR	PIN	WIRE COLOR	SOLDER
A VIDEO RED	WHITE/RED	A 1	WHITE/GREEN	VIDEO GREEN 1
B VIDEO BLUE	WHITE/BLUE	B 2	WHITE/YELLOW	VIDEO SYNC 2
C SPEAKER	GREY/GREEN	C 3	BLACK	VIDEO GROUND 3
D		D 4		4
E		E 5		5
F		F 6		6
G		G 7		7
H		H 8		8
J		J 9		9
K START SW.	YELLOW/BLACK	K 10		10
L SMALL/ODDS SW.	YELLOW/WHITE	L 11		11
M PLAY SW.	YELLOW/RED	M 12		12
N TAKE SCORE SW.	YELLOW/BROWN	N 13		13
P DOUBLE UP SW.	YELLOW/ORANGE	P 14		14
R		R 15		15
S		S 16		16
T BIG SW.	YELLOW/GREEN	T 17		17
U		U 18		18
V COIN A IN	GRAY	V 19		KEY IN 18
W COIN O IN		W 20	BROWN/GREEN	COIN D IN 19
X ANALYZER SW	BLUE	X 21	GRAY/BROWN	CONFIRM SW. 20
Y		Y 22		CLEAR SC. SW. 21
Z		Z 23		22
a	GRAY/PINK	a 24		23
b		b 25		24
c		c 26		25
d		d 27		26
e		e 28		27
f CLEAR SC. CTR.	BROWN/RED	f 29		28
g D. UP LAMP	PINK/ORANGE	g 30		29
h TAKE LAMP	PINK/BROWN	h 31		30
i BIG LAMP	PINK/RED	i 32		31
j SMALL LAMP	PINK/GREEN	j 33		32
k START LAMP	PINK/VIOLET	k 34		33
l PLAY LAMP	PINK/BLACK	l 35		34
m		m 36		35
n		n 37		36
p GROUND	BLACK	p 38	BLACK	GROUND 30

COIN
S 176HCOIN
M 176R

P

POWER SUPPLY EDGE CONNECTOR

A JUMPER	BLACK	A 1	BLACK	JUMPER 1
B GROUND	BLACK	B 2	BLACK	GROUND 2
C +5 VOLTS	RED	C 3	RED	+5 VOLTS 3
D +6 VOLTS	RED	D 4	RED	+8 VOLTS 4
E +12 VOLTS	ORANGE	E 5	ORANGE	+12 VOLTS 5
F		F 6		6
G		G 7		7
H		H 8		8
J		J 9		9
K BLACK	BLACK	K 10	BLACK	BLACK 9
L BLACK	BLACK	L 11	BLACK	BLACK 10